

**BC/BF Engine Trouble Codes**

11	Crank sensor	31	TPS
12	Starter switch	32	O <sub>2</sub> sensor
13	Cam sensor	33	VSS
14	Injector 1	35	Purge valve
15	Injector 2	41	Fuel trims
16	Injector 3	42	Idle switch
17	Injector 4	44	Boost control
21	Temperature sensor	45	Pressure sensing
22	Knock sensor	49	Wrong MAF
23	MAF sensor	51	Neutral switch
24	IAC valve	52	Park switch